

# NEC

# Tech Tip

**Date:** 03/28/2005

**Number:** NEC0090

System	Software
DS1000 / DS2000	All

**Title:** Setting Up Flash Key on BDS Cordless Telephone - DS1000/DS2000

Use the following procedure to set up a Flash key on a BDS Cordless Telephone (P/N 80683).

1. Program a System Speed Dial bin with the following entries:  
LINE/GRP/ICM = 90  
NUM = FP (Flash + Pause), entered by press FLASH followed by MIC.
2. Assign the System Speed Dial bin to one of the four available programmable keys on the cordless telephone.

This key allows the cordless telephone user to flash an outside line and take advantage of whatever features are provided by the connected telco (such as Call Waiting).